

Content

- Portfolio
- Premium & Universal
- New Sulapac Barrier for emulsions
- Sulapac Nordic Collection
 by Quadpack
- Sulapac Antonella collection by HK Cosmetic Packaging
- Sulapac for cosmetics by Nissha
- Compacts by Toly
- Sulapac material texture and available colours
- Compatibility of Sulapac materials
- Testing guidance
- Storage and transportation
- Recycling / Compostability
- Consumer communication
- Key Features of Sulapac



PREMIUM & UNIVERSAL MATERIALS FOR OIL-BASED FORMULATIONS

Great fit for: Anhydrous bulks Solid formulations



SULAPAC BARRIER FOR EMULSIONS

NEW SULAPAC BARRIER

Unique, patent pending solution


Great fit for: Anhydrous bulks Solid formulations Emulsions







SULAPAC BARRIER – PATENT PENDING INNOVATION



WVTR g/(m2*24h), OTR cm3/(m2*24h) *Based on literature

SULAPAC NORDIC COLLECTION BY QUADPACK

🗙 QUADPACK









	15 ml	30 ml	50 ml Double-wall with Sulapac Barrier	200 ml Single-wall
	Ø 47 mm h: 27 mm	Ø 55 mm h: 29 mm	Ø 60 mm h: 38 mm	Ø 82 mm h: 70 mm
Anhydrous bulks	\checkmark		\checkmark	\checkmark
Solid formulations	\checkmark		\checkmark	\checkmark
Emulsions	x		\checkmark	x
Sulapac Premium	\checkmark		\checkmark	x
Sulapac Universal	\checkmark		\checkmark	\checkmark
Liner / Gasket options	Sulapac for anhydrous products		PE for emulsions and Sulapac for anhydrous products	Sulapac for anhydrous products

SULAPAC ANTONELLA COLLECTION BY HK COSMETIC PACKAGING



	50 ml	65 ml	100 ml	
	Ø 59 mm h: 42.2 mm	Ø 59 mm h: 42.2 mm	Ø 68.5 mm h: 50 mm	
Anhydrous bulks	\checkmark	\checkmark	\checkmark	
Solid formulations	\checkmark	\checkmark	\checkmark	
Emulsions	\checkmark	\checkmark	\checkmark	
Sulapac Premium	x	x	x	
Sulapac Universal	\checkmark	\checkmark	\checkmark	
Liner / Gasket options	PE-liner	PE-liner	PE-liner	

SULAPAC FOR COSMETICS BY NISSHA

	9ml	7ml	133ml	200ml
	Ø 40 mm h: 23,5 mm	Ø 30,6 mm h: 24,7 mm	Ø 66,2 mm h: 55,5 mm	Ø 73 mm h: 76,1 mm
Anhydrous bulks		,	(
Solid formulations	\checkmark			
Emulsions	x			
Sulapac Premium	✓ (only bottom)	:	\checkmark	
Sulapac Universal	\checkmark	,	\checkmark	
Liner / Gasket options	Sulapac for anhydrous products			

COMPACTS BY TOLY



	Infinity 31 mm	Infinity 59 mm	
	Ø 42,20 mm h: 8,20 mm	Ø 72,00 mm h: 10,90/17,70 mm	
Godet recess	Ø 31,00 mm h: 4,50 mm	Ø 59,37 mm h: 6,95 mm	
Sulapac Premium	x	x	
Sulapac Universal	\checkmark	\checkmark	
Mirror	x	\checkmark	
Applicator	х	6 mm sponge	

Sulapac materials are currently being promoted using Toly's Infinity Stock Line, but Sulapac material is also available in several other stock lines of Toly. More information available on request.

SULAPAC

Sulapac® Colour Masterbatches for Premium & Universal



Premium

Universal



The ultimate appearance of the color depends on the material recipe it is applied to. Lids: Sulapac[®] Premium Bottoms: Sulapac[®] Universal

RECOMMENDED COMPATIBILITY TESTING CONDITIONS

Sulapac packaging Stability with Cosmetic Bulk

Conventional plastic is traditionally tested with high temperature and humidity. These conditions within certain parameters will initiate the biodegradation process for Sulapac material. This page defines recommended parameters how the tests should be conducted.

The compatibility test of Sulapac materials and cosmetic bulk is recommended in following conditions:

• 40°C (104°F), RH 40-50%, 12 weeks

These test conditions simulate the shelf life of 1 year for Sulapac materials.

Please note, that the changes in the cosmetic bulk may be caused by high ambient temperatures and not necessarily by the jar or barrier materials. The cosmetic bulk should not be exposed to temperature above 45°C.

Recommended max. temperature for temporarily filling 70°C (158°F) 70°C (158°F).

In case disinfection is required, the products can be sprayed with a 70% ethanol solution. The products should be allowed to dry properly before filling.

General Testing Recommendations

Practice-relevant testing is recommended according to what purpose the end-product is made for and its properties or regulatory requirements.

In general, Sulapac materials are not applicable for use and testing at temperatures above 45°C.

Results are based on accredited laboratory and in-house testing.

Please keep in mind that the material is designed to be biodegradable in industrial compost, where the biodegradation is extremely fast and according to standard. The conditions in industrial composting are above 50°C and 60%+ relative humidity to initiate fast biodegradation process according to standard.

If you have question and/or need assistance in test design, please contact us.

Alterations to recipes to suit your application may be done in joint development projects.

Ask for more detailed information and technical support directly from your Sulapac Account Manager.

STORAGE AND TRANSPORTATION INFO

Recommended storage and transportation conditions for Sulapac packaging:

Low relative humidity (under 50% RH), not exposed to extreme temperatures or direct sunlight, best in dry conditions and room temperature (22-25°C max. 45°C or 68-77°F max. 113°F).

		Relative humidity, rH				
		10%	35%	50%	75%	98%
Temp.	-10°C	3+ y	3+ y	N.A.	N.A.	N.A.
	2025°C ^b	3+ y	3+ y	3 у	18 mo	-a
	4045°C	2 y	2 y	1 y	72 h	-


^a Degradation begins, ^b Room temperature, Please note that the recommended temperatures are estimates.

CONSUMER COMMUNICATION

Communicating about Sulapac on your product, web and sales materials is key for tapping into the benefits of the Sulapac brand. In addition, we provide a range of activities that enhance brand awareness and accelerate sales.

Although each of our partners communicates about Sulapac in their own manner, it is crucial that the key principles are carefully followed. This is to guarantee the credibility of both brands, the truthfulness of the message and the best possible outcome.

https://www.sulapac.com/for-partners




CONSUMER COMMUNICATION AND PACKAGING LABELING FOR COSMETICS

Consumer communication

- Like nature
- Bio-based
- Not leaving permanent microplastics behind

Recycling instructions



*Check your local instructions *Sulapac material specific. Each product needs to be tested separately. Please put the PE-liner inside the lid to its own recycling stream. Sulapac liner can be recycled via industrial composting.*

Please put cardboard to cardboard recycling

QR code directs customer to read more about the packaging

SULAPAC FOR COSMETICS - KEY FEATURES



UNIQUE LOOK AND FEEL

Beautiful natural appearance based on unique combination of raw materials.



SUSTAINABLY SOURCED

Made of responsibly sourced sustainable raw materials including wood from industrial side streams. $^{\rm 3}$



BIO-BASED

Main components are wood and plant-based binders. The renewable material content in standard Sulapac Universal and Premium grades is 100%.



INDUSTRIALLY COMPOSTABLE

Industrially compostable based on raw materials.



NO PERMANENT MICROPLASTICS

Circulates back to natural components – just like tree leaves. Can be digested by naturally occurring microorganisms.



SAFE FOR PEOPLE AND PLANET

The material is not considered harmful to aquatic organisms nor to cause long-term adverse effects in the environment.

1. USDA BioPreferred certified. 2. Made of wood chips and biodegradable biopolymers. 3. Our wood originates from certified forests. We always follow our strict Policy for Sustainable Sourcing. 4. The guidelines for sorting and collection of biowaste may differ regionally. Please check the details from your municipality or local waste management authority. 5. The material is not considered harmful to aquatic organisms nor to cause long-term adverse effects in the environment. Ecotoxicity and threshold values for heavy metals tested. All Sulapac materials are in compliance with EU food contact legislation.

Summary



Beautiful Material that wows customers SULAPAC



Functional No compromises

Sustainable Throughout the value chain Accelerating the plastic waste-free future with materials that are SUSTAINABLE, BEAUTIFUL and FUNCTIONAL. *Like nature.*



SULAPAC

* * * * * * * # *

Sulapac has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 829681 @SULAPAC f Y in D www.sulapac.com